

# Stainaway

Chlorine-free bleaching agent



Stainaway is a non-chlorine bleaching agent for the destaining of teapots, urns, crockery and other items subject to tannin and related staining. It is very effective as a colour safe booster to laundry washing procedures for

removing stains from fabrics.

## BENEFITS

- Food Area Use – Stainaway is safe for use in food environments.
- De-staining Power – A powerful tannin de-stainer ideal for crockery, cups and cutlery.
- Non-residual – Does not leave a distasteful residue on cups and glasses.
- Laundry Use – An effective additive to washing powder for stain removal from fabrics.

## Where to use:

- On all crockery, urns, teapots, cutlery and other kitchen utensils.
- As a cleaning booster in laundry procedures.

## DIRECTIONS for USE

Read safety directions before use.

## CLEANING

- Crockery: Dilute 1 heaped tablespoon in 5 litre hot water (at least 60°C) and allow cups, saucers, cutlery, teapots to soak for 30 to 60 minutes.
- Laundry: Add 1 part Stainaway to 10 parts laundry powder and launder stained articles at a temperature above 60°C.

## TIPS

Keep container closed to retain maximum performance.

## PRODUCT SPECIFICATIONS

**pH:** 11 - 12 RTU

**Dilution:** See above

**Fragrance:** None

**Safety:** Non-hazardous

**Colour:** White powder

**Packaging:** 4.5kg, 10kg & 20kg

